



Application instructions

for large stickers with transfer foil

What you need:

- Your sticker with the transparent transfer film (the top layer).
- A cloth and spirit to clean the area where the sticker is to be placed later.
- Adhesive tape
- Scissors or a cutter
- Plastic squeegee (alternatively: old bank card or ice scraper)
- Folding rule or tape measure
- A hairdryer if necessary
- A little patience and fun!

Step 1: Preparation

First you need to clean the area where the sticker is to be placed. Use a cloth with a little spirit and wipe the area well. It must be completely dry, clean and free of grease for the sticker to adhere properly.

Step 2: Prepare the sticker

Now take a closer look at your sticker. It consists of three parts:

1. **The back (paper)** - this is peeled off straight away.
2. **The sticker itself** - this is the motif.
3. **The transfer film (transparent)** - this holds everything together.

Place the sticker on a flat surface and apply a little pressure with the plastic squeegee over the transparent film so that the sticker adheres well.

Step 3: Place the sticker

Now it's time to stick the sticker in the desired place with some adhesive tape. Then stick a strip of adhesive tape vertically completely over the center of the sticker to hold it in place.

Step 4: Attaching the sticker

Now remove the transfer film from the paper up to the adhesive strip from bottom right to top right and fold the sticker with the transfer film over to the left-hand side. Then cut off the remaining paper. Then slowly fold the sticker over again and press it down using a plastic squeegee. Then fold over the left-hand side of the sticker and remove the paper. Now fold the sticker over again and press everything down with the plastic squeegee.

The sticker should now rest for 15 minutes to allow the adhesive to set.

Step 5: Remove the transfer film

Now slowly peel off the transparent transfer film. Make sure that the sticker remains on the surface. If it comes off a little, press the area firmly again and continue pulling.

Step 6: Done!

Your sticker is now perfectly applied.

Good to know!

Bonding temperature: The film should not be bonded at temperatures below 10 °C. If the substrate is too cold, it should be warmed up beforehand with a hairdryer. At higher temperatures, the film should be applied in the shade, as it sticks more quickly when warm.

Air bubbles: If bubbles have formed during application, you can prick them carefully with a small needle and squeeze out the air with the plastic squeegee. Smaller bubbles will self-adhere after several days.

Folding: Heat the folds in the film with a hairdryer and carefully press them out with a squeegee or finger. Start from the center and work outwards.

Remove the film again: Heat the film and slowly remove it at the corners, using a cutter if necessary. Fold the corners of the film over by 180° while heating them continuously with a hairdryer and peel them off. Very careful peeling will leave less adhesive residue on the surface. Adhesive residues can be removed with a solvent such as acetone, turpentine or white spirit.